







This manual contains usage instructions and important cautions, read it and store it!

WARNING: Do not use this product before reading the instructions. IT IS IMPORTANT TO READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

TERPSEALS FUNCTIONS



THE FIRST PROFESSIONAL ASPIRATOR



- 1) Terpseals Temperature Jar: Real time temperature indicator, Press the 🕒 key to switch between
- 2) Terpseals Humidity Jar: Real time Hygrometer.
- 3) Terpseals Jar battery: When the display is charging, the light on the display flashes; when it is fully
- 4-5) Personalized Storage Record: To set the exact date of storage of your terp, press 3-5 seconds 🕲 to set
- 6) Terpseals Automatic Vacuum Control: ON means the system is active , detecting the in-jar pressure automatically and fixing any air loss if detected. OFF means the system is turned off.
- 7) Terpseals Vacuum System Unlock: Press and hold for 3-5 seconds to Unseal.
- 8) Terpseals Vacuum system lock key: pres it once to start to seal and vacuum the jar. Press and hold for 3-5 seconds to pause and use the best seal for you!
- 9) Terpseals Store Time: Click Once To switch from F/C, Press and hold for 3-5 seconds to reset the time of

-1-

10) Type C plug.

HOW TO USE TERPSEALS



Place the Terpseals digital lid on top of the jar, making sure the seal adheres well to the jar structure.



Swipe your finger across the display to turn it on and interact with it. The display will automatically turn off after 5 seconds of inactivity.



inside of the jar. The display will show "On" indicating that the vacuum system is active



Monitor the internal humidity using the digital display. Switch from Fahrenheit to Celsius by pressing the \circ button once.

Reset the storage time by holding the \circ button for 3–5 seconds until the calendar shows 00M 00D. From that moment, the month and day counter will begin. (Hours are not shown but are tracked by the calendar



Hold the 6 button for 3–5 seconds to release the vacuum and open the jar. Once opened, the display will show "OFF" as the vacuum system is deactivated.



Press the a button once to vacuum seal the jar. The display wi show "On" indicating that the vacuum and vacuum co snow "On" indicating that the vacuum and vacuum control system are active. Every time a small amount of air (20% of the capacity) enters the jar, it will automatically re-seal. To deactivate the vacuum control, hold the a button for 3–5 seconds. The display will show "OFF" indicating that vacuum control is off, although the jar remains vacuum sealed. To reactivate the vacuum control, press the button once.

- 2 -

PT.2 HOW TO USE TERPSEALS

- 1) Start: Insert the jar lid onto the Jar and make sure that the lid fits well.
- 2) Press the display: Press the display to light it up; the display stays on for 5
- 3) Seal: Vacuum and seal the jar by holding down the 🖹 button.
- 4) Unseal: Unseal the Jar by holding down the 🛎 button.
- 5) Storage Time: Press the @ for 3-5 seconds to reset the the store time.
- 6) Time Display: $\ \ \, \mathbb{D} \,$ stands for Day and $\ \ \, \mathbb{M} \,$ for Month.
- 7) Automatic Vacuum: While you are storing, Terpseals will monitor the air pressure and vacuum conditions. When the negative pressure leakage exceeds a specific thresold, the system will initiate the vacuum process automatically and
- 8) Temperature and Humidity: The display will show the real-time percentage of humidity and temperature inside the jar. You can switch between Farheneit and Celsius by pressing the ⁽¹⁾ button.
- 9) Power Display: The battery logo will flash when charging, and it will stop when the battery is fully charged.

A CAUTION & ATTENTION

- 1) Terpseals Jar is fragile and must be kept properly, Please keep away from the reach
- 2) For safety reasons, the plastic bag is exclusively designed for wrapping the vacuum container. To prevent the risk of suffocation, please ensure it is kept away from infants and children. Avoid using this bag in cribs, beds, or playpens, as it is not intended for such purposes and is not a toy.
- 3) Do not store liquid in the jar and never place the jar upside down when there is
- 4) When heating, none of the components of this product should be directly exposed to open flame or an induction cooker to prevent thermal deformation and damage.
- 5) Please note that the lid and batteries in Terpseals are precision components. Do not place the lid in microwave for heating or expose it to temperature below 32F / OC. The container is Made of Inox, with a heat resistance range of 20~350F / -7~180c. RANGE TEMPERATURE 20 to 350F / -7 to 180c.
- 6) To clean Terpseals Jar and lid, do not submerge the lid in liquid, and it is strictly prohibited to clean it with water at temperatures above 140F/60c, Do not use steel wool, abrasive cleaners, or corrosive liquids (such as gasoline, acetone) to clean the product. Do not put the lid in the dishwater for cleaning, the inox jar is Dishwasher safe. THE LID CONTAINS BATTERY!
- 7) Seals the best terps! Terpseals need the terps!

SEAL AND VACUUM YOUR TERPS LIKE NEVER BEFORE

- 1) Clean the jar after every usage; you can use a damp cloth and then dry the surfaces with a dry one. USE A DAMP CLOTH.
- 2) Ensure Terpseals is dry and clean before using and storing it.
- 3) Keep Terpseals in a dry place and away from direct sunlight.
- 4) Seal the terps.

TERPSEALS PARAMETERS

Rated Wattage: 3W

Rated Voltage: 5V







